Precision Geodesy after Y-Code

For high-accuracy, high-productivity GPS survey applications, today's advanced receiver system must collect and measure all observables as well as optimize signal processing, enhance jam immunity, multipath rejection and signal to noise.

Ashtech's unique P-W Tracking tracks P-Code signals under AS ("anti-spoofing") conditions by

breaking the encrypted Y-Code into two components, the original P-Code and the W-Code used to encrypt the P-Code.

With P-W Tracking, satellite signals are correlated with locally generated versions of the P-Code (without the limiting and obsoleted cross-correlation technique) and integrated over the W-Code chip intervals.

All observables remain pure GPS (direct code and full-wavelength carrier on both frequencies) as if the Y-Code had not been invoked. It also provides a 13dB signal-tonoise improvement over the so-called "Sixth Observable."

P-W Tracking is an upgrade option for all Ashtech GPS receivers equipped for dual-frequency operation. Call for details



When AS is on, don't be limited to cross-correlation or fictitious observables!

Only Ashtech has state-of-the-art P-W Tracking.

ASHTECH

OBSERVABLES
...all the time!

1170 Kifer Road, Sunnyvale, CA 94086 1-800-229-2400 Phone (408) 524-1400 Fax (408) 524-1500

Don't get caught with your signals crossed!

A critical look at P-Code squaring, code-correlation plus squaring and the so-called "6th Observable."

Accurate and efficient GPS surveys require complete information from both L1 and L2 frequencies; today's advanced systems must:

- Collect all available observables
- Accurately measure all observables
- Optimize signal processing to enhance jam immunity, multipath rejection and signal-to-noise improvement


When available, correlation of P-Code on L1 and L2 along with range and phase data used in conjunction with C/A code processing produces the best results. No codeless technique can recover GPS signal information as well as one which makes use of the modulating code.

However, when AS (Anti-Spoofing) is activated, the P-Code is replaced with Y-Code on L1 and L2 carriers, precluding the use of traditional P-Code correlation techniques. Under these circumstances, GPS receiver manufacturers use different techniques to recover L2 carrier and code phases in the presence of AS:

- Squaring
- Code-correlation plus squaring
- Cross-correlation
- Tracking underlying P-Code and W-Code components of Y-Code

Squaring


Squaring, or auto-correlating L2, produces a half-wavelength carrier signal at twice the center frequency (Figure 1), resulting in a very low signal -to-noise ratio, approximately 30dB lower than that obtained by correlation with the code. Squaring




rules out the use of the 86cm L2 - L1 widelane observable since it halves the L2 carrier wavelength.

Code Correlation Squaring

This method (Figure 2) involves correlating the L2 Y-Code signal with a locally-generated replica of the



underlying P-Code, narrowing the bandwidth and subsequently squaring. This results in a half-wavelength carrier-phase observable and a signal-to-noise 17dB lower than that obtained by correlating with the P-Code.



not be

P-W

the fac

and a

is red


Cross-Correlation

Figure 3 illustrates cross-correlation in which a variable delay is introduced in L1. Two observables result from this process; the range difference between L1 and L2 and a beat frequency carrier (L2 - L1). Since there is no direct measurement of L1 and L2, the pseudorange differences between L2 and L1 codes plus the beat-frequency carriers are used, along with the C/A code, to create the so-called "Sixth Observable."

Because the power of the L1 ranging signal is twice that of L2, cross-correlating results in a 3dB SNR improvement over squaring, however, the L2 observables suffer severe SNR degradation (up to 27dB) when cross-correlation is used instead of direct correlation with the P-Code.

P-W Tracking

Ashtech's unique P-W Tracking methodology (U.S. Patent No. 5134407) tracks the P-Code signal when encrypted (Anti-Spoofing on), by breaking the encrypted Y-Code into two components; the original P-Code and the W-Code used to encrypt the P-Code.



With this technique, satellite senals are correlated with locally enerated versions of the P-Code (no coss-correlation) and integrated over Code chip intervals.

ength

ion

0-

ult

r-

eat

f L1

ices

ed,

ate

ngss-R ever,

NR

ross-

e

This technique produces "pure" GPS bervables (direct code and full wavelength carrier on both frequencies) been dependently, as if the Y-Code had been envoked. It should not be confused with inferior cross-correlation called "Sixth Observable") technique that provides much lower constraints and no direct Y-Code beasurements.

P-W Tracking makes use of the fact that the Y-Code is the modulo two sum of the P-Code and a substantially lower rate encrypting code W. L1 and signals are first correlated with locally generated eplicas of the underlying P-Code, then the bandwidth reduced to that of the

encrypting code and, finally, they are applied to the opposite frequency signal processing (see Figure 4).

System Comparison Chart Figure 5 shows that Ashtech P-W Tracking offers substantial advantages:

- The L1 and L2 Y-Code ranges a re available (the same observables obtained by correlation with the P-Code) as are full-wavelength L1 and L2 carrier phases from direct tracking.
- Signal-to-noise is improved by 13dB over cross-correlation and 3db over code correlation.

Figure 5. System Comparison Ashtech Code Cross Parameters Squaring Correlation Correlation Tracking Squaring C/A Code Yes Yes No Y1 & Y2 Y Code No Y **Y2** (Y2-Y1)Wavelength Half Half Full Full SNR -16 dB .3 dR .13 dR 0 dR

Commercial Considerations of GPS Y-Code Encryption

The Defense Department's need for exclusive access to real-time, 10-meter level GPS accuracy (SA) plus protection against fake signals (AS) collides with many civilian needs which also require

real-time, sub-meter and even centimeter-level accuracy. Differential GPS is a technical solution to SA, but encryption of P-code to Y-code (under AS) forces commercial GPS users to investigate alternate techniques for high-accuracy, high-


productivity applications.

Ashtech's unique P-W Tracking technique breaks the Y-Code into its P-Code and W-Code components which are tracked separately, correlated with locally-generated P-Codes and integrated over the W-Code chip intervals. This method, different from any existing or reported technique, requires no code "cross correlation" or even "squaring." The observables are all pure GPS observables (direct code and full-wavelength carrier on both frequencies) as if the Y-Code had not been envoked.

Ashtech's P-W Tracking satisfies civilian needs, but it does not conflict with the DoD's AS objectives, indeed, it affords the best geodetic surveying and precision navigation system performance in the presence of AS.

P-W Tracking is an upgrade option, available for installation in all Ashtech M-Series GPS receivers equipped for dualfrequency operation, beginning in the first quarter of 1993.





DIMENSION...the compact GPS receiver with accuracy equal to the dimensions of a dime!

• Millimeter-level accuracy for precision static, kinematic and pseudo-kinematic surveying

• Decimeter-level accuracy for static GIS applications

- Meter-level for dynamic GIS data logging
- "All-In-View" 12-channel tracking
- Up to 8 megabytes of internal memory
- Compact (9" dia), sealed weather-proof aluminum case with high-impact antenna dome protects GPS antenna, receiver and internal memory
- Fully automatic...green light indicates that satellites are being tracked and data recorded

- RS-232 ports for simultaneous data transfer and communications, including realtime differential GPS
 - Interface with various hand-helds for optional control and attribute tagging (not required for most field operations)
- Optional lightweight "PowerPole" supplies 12-volt power for cordless one-hand operation
- Battery charge level indicator
- Call Ashtech for complete information about DIMENSION AS Well aS RANGER, M-XII, DUAL P-CODE and other Ashtech GPS receivers.

524-1500 • Phone (408) 524-1400 ASHTECH